



CYL. SIZE	DIM. Y	DIM. X
	0.517	1.125

INSTALLATION PROCEDURE:

1. REMOVE OLD INSERT.
2. SNAP FILLER ONTO CONNECTING ARM.
3. ASSEMBLE CYLINDER AND COLLAR TO INSERT WITH CYLINDER NUT.
4. ASSEMBLE LOCKDOWN CAM ASSEMBLY TO INSERT WITH 4 SCREWS.
5. SLIDE INSERT INTO RAIL ASSEMBLY.
6. MAKE OPERATIONAL CHECK OF DOGGING (TURN COUNTERCLOCKWISE TO DOG).
7. PRESS PLUG INTO ALLEN WRENCH LOCKDOWN BUTTON.

NOTES: WHEN INSERT IS USED (1) SLIDE INSERT INTO RAIL, (2) DOG PUSH RAIL,

6605 Flotilla St.
 City of Commerce
 CA 90040 USA
 Tel: (323) 888-6601
 FAX: (323) 888-6699
 Website: cal-royal.com
 Email: sales@cal-royal.com

DESCRIPTION:			SCALE:
CYLINDER DOGGING KIT ASSEMBLY AND INSTALLATION INSTRUCTIONS FOR 2200/2260, 9800/9860 SERIES PANIC RIM AND VERTICAL ROD DEVICE			NOT TO SCALE
ANSI:	UNIT:	VERSION:	BY:
	inches [mm]	ver. 1.0 rev. 04/12	bteves/adg