


FLR2298 (Previously CRLP98-UL-M-KIT)



INSTALLATION INSTRUCTIONS

FLR2298, previously CRL98P-UL-M-KIT is a field installable motorized latch-pullback kit for the Cal Royal 98 series.



Kit Includes

- A. 1 - 5/32" Drill Bit
- B. 1- Motor Mount Assembly
- C. 1 - 6' Lead
- D. 2 -Phillips Screws
- E. 1 - 5/64" Hex Wrench

Tools Required

- Power Drill

STEP 1 - Disassemble Exit Device

A. Remove End Cap & Filler Plate



B. Remove (4) screws from baserail





C. Partially slide push pad off approx. 2-3"



D. Using 5/32" drill bit. Open up the (2) back screw holes #3 & 4.




E. Continue sliding push pad half way out of the base rail so activating bracket is accessible. Next, remove metal rod and AB mount can be put aside.



STEP 2 - Install Motor Mount

A. Attach the link assembly to the end of the activating bracket. Next, place activating bracket into center of the motor mount.



B. Secure link assembly to activating bracket with Hex wrench provided.



C. Re-install metal rod securing activating bracket to motor mount.



STEP 4 - Install MM3 & Reassemble Device

A. Slide push pad with motor kit back into the device. Also, the filler plate must be slid in at some time.



B. Make sure Latch retractor is pressed down so push pad slides over it.



C. Re-install original screws in holes 1 & 2. Install new screws provided in holes 3 & 4.



Next Set the MM3 "PTS" (Push to Set) adjustment. . .





TECHNICAL INFORMATION

Specifications

- Input Voltage: Regulated 24VDC +/- 10%
- Current Peak: 1 Amp
- Current Hold: 125 mA
- Wire gauge: X ≥ 20 ga



Wiring Color Code

Setting Push to Set Adjustment

- Step 1-** Press the device push pad to the desired setting. (this can be fully depressed or less than fully depressed).
- Step 2-** While depressing the push pad, apply power. (i.e. presenting the credential to the reader).
- Step 3-** Continue to keep pad depressed, the device will beep 6 times. After the beeps have stopped, release the pad and now the adjustment is complete. If not to your liking repeat the three steps. That's all there is to it.

Troubleshooting & Diagnostics

Beeps	Explanation	Solution
2 Beeps	Over Voltage	Check voltage & adjust to Regulated 24 V.
3 Beeps	Under Voltage	Check voltage & adjust to Regulated 24 V.
5 Beeps	Forced Release	Device will automatically re-engage within 5 seconds.
7 Beeps	Over-travel or mechanical obstruction	Remove obstruction & push pad down until beeping stops & release.